

## Installation procedure

Simple to install, no nails, screws or exact cuts, seamless plaster finish coating, inside & outside pre-cut corners available, a breeze to paint!

Cutting is smooth and as easy as using a wood saw and a miter box. Trimroc™ recommends the use of gypsum based adhesives commercially available at hardware supply stores.



First measure the size needed.



Use a miter box for cutting corner angles. Saw through clean and smoothly.



Cut for inside corners.



Cut for outside corners. Premitred inside and outside corners are also available.



After mixing the required amount of adhesive (toothpaste consistency), apply a bead of adhesive to the top and bottom edges.



Press the moulding into place and the compound holds the moulding to set. No nails, braces and support.



Clear away the excess compound.



Use a moist sponge to clean away any dried compound. Wipe the area clean.



Fill joints with compound using a putty knife.



Scrape away excess.



Use a wet sponge to clean up.



Sand away dried compound for an invisible seam. Finished joint should be smooth, ready to prime and paint.